

Apéndice C

Manuales de los instrumentos

C.1 Fuente de alimentación MPD-3305D, Manual de usuario



MYWAVE®

MPD-3305D

Multi-channel Programmable DC Power Supply Operation Manual



Part No. PPOM-010110E



Contents

SAFETY INSTRUCTION	II
1. OVERVIEW	- 1 -
1.1 Operation and Storage Environment.....	- 1 -
1.2 Introduction	- 1 -
1.3 Series Lineup/Main Features.....	- 2 -
1.4 Principle of Operation.....	- 3 -
1.5 Front Panel Overview.....	- 4 -
1.6 Rear Panel Overview.....	- 7 -
1.7 CV/CC Crossover Characteristics	- 8 -
2. SETUP	- 9 -
2.1 Power Up	- 9 -
2.2 Load Cable Connection.....	- 9 -
2.3 Output ON/OFF.....	- 10 -
2.4 Beep ON/OFF.....	- 10 -
2.5 Front Panel Lock	- 10 -
3. OPERATION	- 11 -
3.1 CH1/CH2 Independent Mode.....	- 11 -
3.2 CH3 Independent Mode.....	- 11 -
3.3 CH1/CH2 Tracking Series Mode.....	- 12 -
3.4 CH1/CH2 Tracking Parallel Mode	- 15 -
4. SAVE/RECALL SETUP	- 17 -
4.1 Save Setup	- 17 -
4.2 Recall Setup.....	- 17 -
5. REMOTE CONTROL (Only for MPD-3303S/3303D/3305D).....	- 18 -
5.1 Remote Control Setup	- 18 -
5.2 Remote Connection Step	- 18 -
5.3 Command Syntax.....	- 19 -
5.4 Error Messages	- 19 -
5.5 Command List.....	- 19 -
5.6 Command Details.....	- 20 -
6. MAINTENANCE.....	- 23 -
6.1 Inspection	- 23 -
6.2 Fuse Replacement	- 23 -
6.3 Cleaning.....	- 23 -
7. FAQ.....	- 24 -
SPECIFICATIONS (MPD-3303S).....	- 24 -
SPECIFICATIONS (MPD-3303/3305)	- 25 -
SPECIFICATIONS (MPD-3303D/3305D)	- 27 -
SPECIFICATIONS (MPD-3303C/3305C)	- 28 -

Use of Operation Manual

Please read through and understand this Operation Manual before operating the product. After reading, always keep the manual nearby so that you may refer to it as needed. When moving the product to another location, be sure to bring the manual as well.

Calibration notification

We notify that the instruments included in this manual are in compliance with the features and specifications as stated in this manual. Before shipment, the instrument has been calibrated in factory. The calibration procedures and standards are compliant to the national regulations and standards for electronic calibration.

Warranty

We guarantee that the instrument has been passed strict quality check. We warrant our instrument's mainframe and accessories in materials within the warranty period of one year. We guarantee the free spare parts for products which are approved defective in this period. To get repair service, please contact with your nearest sales and service office. We do not provide any other warranty items except the one being provided by this summary and the warranty statement. The warranty items include but not being subjected to the hinted guarantee items related to tradable characteristics and any particular purpose. We will not take any responsibility in cases regarding to indirect, particular and ensuing damage, such as modifications to the circuit and functions by the users, repairing or component replacement by the users, or damage during transportation.

For product improvement, the specifications are subject to change without prior notice.

SAFETY INSTRUCTION

This chapter contains important safety instructions that you must follow when operating the instrument and when keeping it in storage. Read the following before any operation to insure your safety and to keep the best condition for the instrument.

Safety Symbols

The following safety symbols may appear in this manual or on the instrument:



WARNING

WARNING

Identifies conditions or practices that could result in injury or loss of life.



CAUTION

CAUTION

Identifies conditions or practices that could result in damage to the instrument or to other properties.



DANGER

High voltage



ATTENTION

Refer to the manual



Protective conductor terminal



Earth (ground) terminal

Safety Guidelines



CAUTION

- Before plugging into local AC mains, check and make sure that the output voltage is compatible to the load. (It is suggested to disconnect a load before plugging into local AC mains.
- Do not use this instrument near water.
- Do not operate or touch this instrument with wet hands.
- Do not open the casing of the instrument when it is connected to AC mains.
- The max.output voltage of the instrument may be over 60VDC, avoid touch the metal contact part of the output terminals.
- Do not use the instrument in an atmosphere which contains sulfuric acid mist or other substances which cause corrosion to metal.
- Do not use the instrument in a dusty place or a highly humid place as such will cause instrument reliability degradation and instrument failures.
- Install the instrument in a place where is free from vibration.
- Install the instrument in a place where the ambient temperature is in range of -10~70°C. Note that the instrument operation may become unstable if it is operated in an ambient temperature exceeding the range of 0~40°C

Power supply

AC Input voltage: 110V/220V $\pm 10\%$, 50/60Hz



WARNING

Connect the protective grounding conductor of the AC power cord to an earth ground to avoid electrical shock.

Fuse



WARNING

- Fuse type: 110V: T6.3A /250V, 220V: T3.15A/250V.
- Make sure the correct type of fuse is installed before power up.
- Replace the AC fuse with the same type and rating as the original fuse.
- Disconnect the power cord before fuse replacement.
- Make sure the cause of fuse blowout is fixed before fuse replacement.

Power cord for the United Kingdom

When using the power supply series in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/appliance must only be wired by competent persons.




WARNING: THIS APPLIANCE MUST BE EARTHED.

IMPORTANT: The wires in this lead are coloured in accordance with the following code:

Green/Yellow:	Earth
Blue:	Neutral
Brown:	Live



As the colours of the wires in main leads may not correspond with the colours marking identified in your plug/appliance, proceed as follows:

- The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with the letter E or by the earth symbol  or coloured Green or Green & Yellow.
- The wire which is coloured Blue must be connected to the terminal marked with the letter N or coloured Blue or Black.
- The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any moulded mains connector that requires removal/replacement must be destroyed by removal of any fuse & fuse carrier and disposed of immediately, as a plug with bared wires is hazardous if engaged in live socket. Any re-wiring must be carried out in accordance with information detailed on this label.

1. OVERVIEW

This chapter describes the instrument in a nutshell, including its main features and front /rear panel introduction. After going through the overview, follow the SETUP chapter to properly power up and set operation environment.

1.1 Operation and Storage Environment

Operation Environment

Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (note below)

Relative Humidity: < 80%

Altitude: < 2000m

Temperature: 0°C to 40°C

(Pollution Degree) EN 61010-1:2001 specifies the pollution degrees and their requirements as follows. The instrument falls under degree 2.

Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.

Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.

Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.

Pollution degree 3: Conductive pollution occurs, or dry, nonconductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.

Storage Environment

Location: Indoor

Relative Humidity: < 70%

Temperature: -10°C to 70°C

1.2 Introduction

This series of regulated programmable DC power supply are light weight, adjustable, multifunctional work stations. They have three independent outputs: two with adjustable voltage level and one with fixed level selectable from 2.5V, 3.3V and 5V. The power supply can be used for logic circuits where various output voltage or current are needed, and for tracking mode definition systems where positive and negative voltages with good accuracy are required.

Independent /Tracking Series /Tracking Parallel

The three output modes of the power supply - independent, tracking series, and tracking parallel - can be selected by pressing the TRACKING key on the front panel. In the independent mode, the output voltage and current of each channel are controlled separately. The isolation degree, from output terminal to chassis or from output terminal to output terminal, is 300V. In the tracking modes, both the CH1 and CH2 outputs are automatically connected in series or parallel; no need to connect output leads. In the series mode, the output voltage is doubled; in the parallel mode, the output current is doubled.

Constant Voltage/Constant Current

Except for CH3, each output channel is completely transistorized and well-regulated, and works in constant voltage (CV) or constant current (CC) mode. Even at the maximum output current, a fully rated, continuously adjustable output voltage is provided. For a big load, the power supply can be used as a CV source; while for a small load, a CC source.

When in the CV mode (independent or tracking mode), output current (overload or short circuit) can be controlled via the front panel. When in the CC mode (independent mode only), the maximum (ceiling) output voltage can be controlled via the front panel. The power supply will automatically cross over from CV to CC operation when the output current reaches the target value. The power supply will automatically cross over from CC to CV when the output voltage reaches the target value. For more details about CV/CC mode operation, see page8.

Automatic Tracking Mode

The front panel display (CH1, CH2) shows the output voltage or current. When operating in the tracking mode, the power supply will automatically connect to the auto- tracking mode.

Dynamic Load

When used in audio production lines, the power supply will provide a continuous or dynamic load connector. When the connectors are connected to the position “ON”, a stable DC current power will be provided for audio power amplifiers.

1.3 Series Lineup/Main Features

Series Lineup

Model	Output	Voltmeter	Ammeter	USB Interface
MPD-3303S	0~30V×2, 0~3A×2 Fixed 2.5V/3.3V/5V, 3A	5 digits LED	4 digits LED	√
MPD-3303	0~30V×2, 0~3A×2 Fixed 2.5V/3.3V/5V, 3A	3 digits LED	3 digits LED	_____
MPD-3305	0~30V×2, 0~5A×2 Fixed 2.5V/3.3V/5V, 3A	3 digits LED	3 digits LED	_____
MPD-3303D	0~30V×2, 0~3A×2 Fixed 2.5V/3.3V/5V, 3A	3 digits LED	3 digits LED	√
MPD-3305D	0~30V×2, 0~5A×2 Fixed 2.5V/3.3V/5V, 3A	3 digits LED	3 digits LED	√
MPD-3303C	0~30V×2, 0~3A×2 Fixed 2.5V/3.3V/5V, 3A	3 digits LED	3 digits LED	_____
MPD-3305C	0~30V×2, 0~5A×2 Fixed 2.5V/3.3V/5V, 3A	3 digits LED	3 digits LED	_____

Main Features

Performance	<ul style="list-style-type: none"> ➤ Low ripple & noise, intelligent cooling fan ➤ Compact design, light weight
Operation	<ul style="list-style-type: none"> ➤ Constant voltage/constant current operation ➤ Tracking series/tracking parallel operation ➤ Output ON/OFF control

	<ul style="list-style-type: none"> ➤ 3 outputs: 30V/3A(5A)×2, 2.5V/3.3V/5V/3A×1 ➤ Digital panel control ➤ Panel lock function ➤ 4 programming presets for voltage and current save/recall ➤ Coarse and fine control for voltage and current ➤ Software calibration ➤ Beeper output
Protection	<ul style="list-style-type: none"> ➤ Over load protection ➤ Reverse polarity protection
Interface	<ul style="list-style-type: none"> ➤ USB interface for remote PC control (only for models with USB interface)


1.4 Principle of Operation

The power supply consists of the following:

- AC input circuit
- Transformer
- Bias power supply including rectifier, filter, pre-regulator and reference voltage source
- Main regulator circuit including the main rectifier and filter, series regulator, current comparator, voltage comparator, reference voltage amplifier, remote device and relay control circuit

The block diagram below shows the circuit arrangement. The single phase input power is connected to the transformer through the input circuit. Details of each part are described as below.

Overview



Rectifier	The auxiliary rectifiers D1011~D1014 provide bias voltage filtered by the capacitors C102 and C103, for the pre-regulators U101 and U102. They provide a regulated voltage for other modules.
Main rectifier	The main rectifier is a full wave bridge rectifier. It provides the power after the rectifier is filtered by the capacitor C101, and then regulated via a series-wound regulator, which is finally delivered to the output terminal.
Current limiter	U104 acts as a current limiter. When the current is over predetermined rating, U104 is activated

and decreases the current. U208 provides a reference voltage. U206 is the inverter amplifier. U103 is a comparator amplifier which compares reference voltage and feedback voltage, and then delivers to Q103, Q104, which then calibrates the output voltage.

When the unit is overload, Q107 activates to control the current magnitude of Q104, to limit the output current. The relay control circuit controls the power dissipation in the series-wound regulated circuit.

1.5 Front Panel Overview




Fig.1.5-1 Front panel of MPD-3303S

















Fig.1.5-2 Front panel of MPD-3303/3305/3303C/3305C/3303D/3305D












Display

Voltmeter	Displays CH1 or CH2 output voltage		
		For 1mV, 1mA models (5 digits)	For 10mV, 10mA /100mV, 10mA models (3 digits)
Ammeter	Display CH1 or CH2 output current		
		For 1mV, 1mA models (4 digits)	For 10mV, 10mA /100mV, 10mA models (3 digits)

Control Panel

Memory keys		Saves or recalls panel settings. Max.4 sets for programming preset. Refer to page 17 for details.
CH1/CH2 beep keys		Selects the output channel for level adjustment. Refer to page 11 for level setting details Pressing and holding CH2 key enables beep sound. Refer to page 10 for details.
Parallel/Series keys		Activates Tracking Parallel operation or Tracking Series operation. Refer to page 12 for details.
Lock key		Locks or unlocks the front panel settings. Refer to page 10 for details.
Output key		Turns the output on or off.

VOLTAGE			
Voltage knobs			Adjusts the output voltage level for CH1 or CH2. Pressing the knob switches for coarse and fine level setting. When in fine adjustment, the FINE indicator lights on.
CURRENT			
Current knobs			Adjusts the output current level for CH1 or CH2. Pressing the knob switches coarse and fine level setting. When in fine adjustment, the FINE indicator lights on.

Terminals		
Power switch		Turns on  or off  the main power. Refer to page 9 for power up sequence.
GND terminal		Accepts a grounding wire.
CH1 output		Outputs CH1 voltage and current.
CH1 CV/CC indicator		Indicates CH1 constant voltage or constant current operation mode.
CH2 output		Outputs CH2 voltage and current.
CH2 CV/CC/ PAR indicator		Indicates CH2 constant voltage, constant current or tracking parallel operation mode.
CH3 output		Outputs CH3 voltage and current.
CH3 overload indicator		Indicates when CH3 output current is overloaded.
CH3 voltage selector		Selects CH3 output voltage from 2.5V, 3.3V, 5V.

1.6 Rear Panel Overview




Fig.1.6-1 Rear panel of MPD-3303S/3303D/3305D








Fig.1.6-2 Rear panel of MPD3303/3305/3303C/3305C

USB connector		Accepts a USB slave connector for command-based remote control (page 18). For models with USB interface.
Power cord/fuse socket		The power cord socket accepts the AC mains. Refer to page 9 for power up details. The fuse holder contains the AC main fuse. Refer to page 23 for details of fuse replacement.
AC line voltage selector		Selects AC line voltage from 110V/220V.

1.7 CV/CC Crossover Characteristics

Background	The instrument automatically switches between constant voltage mode (CV) and constant current mode (CC), according to load condition.
CV mode	When the current level is smaller than the output setting, the instrument operates in Constant Voltage mode. The indicator on the front panel turns green (C.V.) The Voltage level is kept at the setting and the Current level fluctuates according to the load condition until it reaches the output current setting.
CC mode	When the current level reaches the output setting, the instrument starts operating in Constant Current mode. The indicator on the front panel turns red (C.C.) The Current level is kept at the setting but the Voltage level becomes lower than the setting, in order to suppress the output power level from overload. When the current level becomes lower than the setting, the instrument goes back to the Constant Voltage mode.

Diagram




2. SETUP

This chapter describes how to properly power up and configure the power supply series before operation.


2.1 Power Up

Select AC line voltage Before powering up the power supply, select the AC input voltage from the rear panel. voltage



Connect AC power cord Connect the AC power cord to the rear panel socket.

Power on Press the power switch to turn on the power. The display shows the initialization screen, followed by the last recalled settings.




Power off Press the power switch again to turn off the power.




2.2 Load Cable Connection

Standard accessory 1. Turn the terminal counterclockwise and loosen the screw.
2. Insert the cable terminal.
3. Turn the terminal clockwise and tighten the screw.



Banana plug Insert the plug into the socket.




Wire type When using load cables other than the attached, make sure they have enough current capacity for minimizing cable loss and load line impedance. Voltage drop across a wire should not exceed 0.5V. The following list is the wire current rating at 450A/cm².

Wire size (AWG)	Max. current (A)
20	2.5
18	4
16	6
14	10
12	16

2.3 Output ON/OFF

Panel operation

Pressing the Output key turns on all CH 1/2/3 outputs.



The key LED also turns on. Pressing the Output key again turns off the output and the key LED.

Automatic output off

Any of the following actions during output on automatically turns it off. They might involve sudden and harmful change in the output level.

- Change the operation mode between independent / tracking series / tracking parallel
- Recalling other setups from the memory
- Storing the setup into the memory

2.4 Beep ON/OFF

Panel operation

By default, the beeper sound is enabled. To turn off the beep, press the beep key for 2 seconds.



A beep sound comes out and the beeper setting will be turned off. To enable the beeper, press the beep key again for 2 seconds.

List of beeper

The following operations go with a beep sound when the beeper setting is on.

Power on

Output on/off

INDEP – SER – PAR mode switching

Panel lock/unlock

Setup save/recall

CH1/CH2 output level knob

Voltage/current knob, fine/coarse knob

Voltage/current level reaching minimum (zero) level

2.5 Front Panel Lock

Panel operation

Press the LOCK key to lock the front panel key operation. The key LED turns on. To unlock, press the LOCK key for 2 seconds. The key LED also turns off.



Note

The OUTPUT key is not affected by the lock operation.




3. OPERATION

3.1 CH1/CH2 Independent Mode

Background/ CH1 and CH2 outputs work independent of each other and are separately controlled.

Connection




Output rating 0~30V/0~3A for each channel ($I \leq 3A$)

0~30V/0~5A for each channel ($I > 3A$)


Panel operation 1. Make sure the PARA INDEP and SERIES INDEP keys are turned off (the key LEDs are off)



2. Connect the load to the front panel terminals, CH1 +/-, CH2 +/-.




3. Set the CH1 output voltage and current. Press the CH1 switch (LED turns on) and use the Voltage and Current knob. By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.



(Fine control)

Coarse: 0.1V or 0.1A @ rotation click.

Fine: the smallest digit @ rotation click.




4. Repeat the above settings for CH2 channel.

5. To turn on the output, press the output key. The key LED turns on and the CH1 /CH2 indicator shows the output mode, CV or CC.


3.2 CH3 Independent Mode

Background/ The CH3 rating is 2.5V/3.3V/5V, maximum 3A. It works independently from CH1 and CH2,

Connection regardless of their modes.



Output rating	Fixed 2.5V/3.3V/5V, 3A
No tracking Series/Parallel mode	CH3 does not have tracking series/parallel mode. Also, CH3 output is not affected by CH1 and 2 modes.
Panel operation	<ol style="list-style-type: none"> 1. Connect the load to the front panel CH3 +/- terminal. 2. Select the output voltage from 2.5V, 3.3V and 5V, using the CH3 voltage selector switch. 3. To turn on the output, press the output key. The key LED turns on.
CV to CC	<p>When the output Current level exceeds 3A, the overload indicator turns red and CH3 operation mode switches from Constant Voltage to Constant Current.</p> <p>Note: “overload” in this case does not mean an abnormal operation.</p>




3.3 CH1/CH2 Tracking Series Mode

Background	<p>Tracking series operation doubles the Voltage capacity of the power supply series by internally connecting CH1 (Master) and CH2 (Slave) in series and combining the output to a single channel. CH1 (Master) controls the combined Voltage output level.</p> <p>The following describes two types of configurations depending on the common ground usage.</p>
------------	--



Tracking series without common terminal

Connection




Output rating 0~60V/0~3A ($I \leq 3A$)
 0~60V/0~5A ($I > 3A$)

- Panel operation
1. Press the SER/INDEP key to activate the tracking series mode. The key LED turns on.
 2. Connect the load to the front panel terminals, CH1+ & CH2-. (Single supply).




3. Press the CH2 switch (LED turns on) and use the Current knob to set the CH2 output current to the maximum level. By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.



Coarse: 0.1V or 0.1A @ rotation click.

Fine: the smallest digit @ rotation click.

4. Press the CH1 switch (LED turns on) and use the Voltage and Current knob to set the output voltage and current level.



5. To turn on the output, press the output key. The key LED turns on.




6. Refer to the CH1 (Master) meter and indicator for the output setting level and CV/CC status.



Voltage level	Double the reading on the CH1 Voltage meter. In the above case, the actual output is $20.0 \times 2 = 40.0V$.
Current level	CH1 meter reading shows the output Current. In the above case, 2.000A. (CH2 Current control must be in the Maximum position= $3.0A(I \leq 3A)$ or $5.0A(I > 3A)$).


Tracking series with common terminal

Connection



Output rating	0~30V/0~3A for CH1~COM ($I \leq 3A$)	0~30V/0~5A for CH1~COM ($I > 3A$)
	0~30V/0~3A for CH2~COM ($I \leq 3A$)	0~30V/0~5A for CH2~COM ($I > 3A$)

- Panel operation
1. Press the SER/INDEP key to activate the tracking series mode. The key LED turns on.
 2. Connect the load to the front panel terminals, CH1+ & CH2-. Use the CH1 (-) terminal as the common line connection.



3. Press the CH1 switch (LED turns on) and use the Voltage knob to set the master & slave output voltage (the same level for both channels). By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.

Coarse: 0.1V or 0.1A @ rotation click.


Fine: the smallest digit @ rotation click.



4. Use the current knob to set the master output current.



5. To turn on the output, press the output key. The key LED turns on.




6. For the master (CH1) output level and CV/CC status, refer to the CH1 meter and indicator.



Master (CH1) voltage level: CH1 meter reading shows the output voltage. In the above case, 20.0V.

Master (CH1) current level: CH1 meter reading shows the output current. In the above case, 2.000A.

7. Press the CH2 switch (LED turns on) and use the Current knob to set the slave output current.



8. For the slave (CH2) output level and CV/CC status, refer to the CH1/2 meter and CH2 indicator.




Slave (CH2) voltage level: CH1 meter reading shows the output voltage. In the above case, 20.0V.

Slave (CH2) current level: CH2 meter reading shows the output current. In the above case, 3.000A.

3.4 CH1/CH2 Tracking Parallel Mode

Background/ connection Tracking parallel operation doubles the current capacity of the power supply series by internally connecting CH1 and CH2 in parallel and combining the output to a single channel. CH1 controls the combined output.




Output rating 0~30V/0~6A (I≤3A)
 0~30V/0~10A (I>3A)

- Panel operation

1. Press the PAR/INDEP key to activate the tracking parallel mode.


The key LED turns on.

2. Connect the load to the CH1 +/- terminals.



3. To turn on the output, press the output key. The key LED turns on.

4. The CH2 indicator turns red, indicating tracking parallel (PAR) mode.



6. For the output level and CV/CC status, refer to the CH1 meter and indicator.




Voltage level: The CH1 meter reading shows the output voltage. In the above case, 20.0V.

Current level: Double the amount of CH1 current meter reading. In the above case,


$2.0\text{A} \times 2 = 4.0\text{A}.$

4. SAVE/RECALL SETUP

4.1 Save Setup


Background	The front panel settings can be stored into one of the four internal memories.
Programming contents	<p>The following list shows the programming setting contents:</p> <ul style="list-style-type: none">➤ Independent / tracking series / tracking parallel mode➤ CH1/CH2 knob selection➤ Fine/coarse knob editing mode➤ Beep on/off➤ Output voltage/current level <p>The following settings are always saved as “off”:</p> <ul style="list-style-type: none">➤ Output on/off➤ Front panel lock on/off
Panel operation	<p>Press one of the 1~4 Memory keys for 2 seconds, for example memory 1. The panel settings will be saved in memory 1 by long push to this key and the key LED turns on. When the panel settings are modified, the LED turns off.</p> 
Note	When the setting is stored, the output automatically turns off.

4.2 Recall Setup





Background	The front panel settings can be recalled from one of the four internal memories.
Programming contents	<p>The following list shows the programming setting contents:</p> <ul style="list-style-type: none">➤ Independent / tracking series / tracking parallel mode➤ CH1/CH2 knob selection➤ Fine/coarse knob editing mode➤ Beep on/off➤ Output voltage/current level <p>The following settings are always recalled as “off”:</p> <ul style="list-style-type: none">➤ Output on/off➤ Front panel lock on/off
Panel operation	<p>Press one of the 1~4 Memory keys, for example memory 1. The panel settings saved in memory 1 will be recalled by pressing this key. The key LED turns on. When the panel settings are modified, the LED turns off.</p> 
Note	When a setting is recalled, the output automatically turns off.

5. REMOTE CONTROL (Only for MPD-3303S/3303D/3305D)

5.1 Remote Control Setup

Background	The power supply is capable of being remotely controlled via the USB connection.	
Interface		USB slave port, rear panel
COM setting	Set up the COM port inside the PC according to the following list: Baud rate: 9600 Parity bit: None Data bit: 8 Stop bit: 1 Data flow control: None	
Functionality check	Run this query command via the terminal application such as MTTTY (Multi-threaded TTY). *IDN? This should return the identification information: series number, firmware version.	

5.2 Remote Connection Step

Enter the remote control mode	<ol style="list-style-type: none">1. Connect the USB cable to the slave port.2. The connection will be automatically established, and the front panel shows “USB...YES” message. 3. The power supply also automatically enters the lock state (the Lock key will be activated). 	
Exit the remote control mode	<ol style="list-style-type: none">1. Disconnect the USB cable from the rear.2. The display shows “USB...NO” message. 3. Unlock the power supply by pressing the Lock key until it turns off backlight. 4. The power supply goes back to local operation mode.	

5.3 Command Syntax

Command format	<div><div>1</div><div>2</div><div>3</div><div>4</div><div>1SET<X>:<NR2></div></div>			1: command header 2: output channel 3: separator 4: parameter
Parameter	Type	Description	Example	
	<Boolean>	Boolean logic	0 (off), 1 (on)	
	<NR1>	Integers	0, 1, 2, 3	
	<NR2>	Decimal numbers	0.1, 3.14, 8.5	
Output channel	1 (CH1) or 2 (CH2)			
Note	Commands must be capital letters			

5.4 Error Messages

The following error messages might appear when the power supply cannot accept the command.

Message contents			Descriptions
a	Program mnemonic too long		The command length must be 15 characters or less.
b	Invalid character		Invalid characters, such as symbols, are entered. Example: VOUT#
c	Missing parameter		The parameter is missing from the command. Example: VSET: (should have a number)
d	Data out of range		The entered value exceeds the specification. Example: VSET:33 (should be ≤32V)
e	Command not allowed		The entered command is not allowed in the circumstance. Example: trying to set CH2 output while in the tracking mode.
f	Undefined header		The entered command does not exist, or the syntax is wrong.

5.5 Command List

Detailed descriptions of each command starts from the next page.

The “HELP” command shows all the following commands and their meanings, except for the HELP command itself.

Command	Meanings
ISET<X>:<NR2>	Sets the output current
ISET<X>?	Returns the output current setting
VSET<X>:<NR2>	Sets the output voltage
VSET<X>?	Returns the output voltage setting
IOUT<X>?	Returns the actual output current
VOU<X>?	Returns the actual output voltage
TRACK<NR1>	Selects the operation mode
BEEP<BOOLEAN>	Turn on or off the beep
OUT<BOOLEAN>	Turn on or off the output
STATUS?	Returns the MODEL status

*IDN?	Returns the MODEL identification
RCL<NR1>	Recalls a panel setting
SAVE<NR1>	Saves the panel setting
HELP?	Shows the command list
ERR?	Returns the instrument error messages

5.6 Command Details

Command	ISET<X>:<NR2>
Description	Sets the output current.
Panel operation	Refer to page 11
Response time	Min.70ms
Example	ISET1:2.234 Sets the CH1 output current to 2.234A. (MPD-3303S) ISET1:2.23 Sets the CH1 output current to 2.23A. (MPD-3303D/3305D)

Command	ISET<X>?
Description	Returns the output current setting
Response time	Min.70ms
Example	ISET1? Returns CH1 output current setting.

Command	VSET<X>:<NR2>
Description	Sets the output voltage.
Panel operation	Refer to page 11
Response time	Min.70ms
Example	VSET1:20.345 Sets the CH1 voltage to 20.345V. (MPD-3303S) VSET1:20.3 Sets the CH1 voltage to 20.3V. (MPD-3303D/3305D)

Command	VSET<X>?
Description	Returns the output voltage setting.
Response time	Min.70ms
Example	VSET1? Returns the CH1 voltage setting.

Command	IOUT<X>?
Description	Returns the actual output current.
Response time	Min.70ms
Example	IOUT1? Returns the CH1 output current.

Command	VOUT<X>?
Description	Returns the actual output voltage.
Response time	Min.70ms
Example	VOUT1? Returns the CH1 output voltage.

Command	TRACK<NR1>
Description	Selects the operation mode: INDEP, tracking SER, tracking PAR
Panel operation	Refer to page 12
NR1	0: Independent 1: Tracking series 2: Tracking parallel
Response time	Min.70ms
Example	TRACK0 Selects the independent mode.

Command	BEEP<Boolean>
Description	Turns on or off the beeper.
Panel operation	Refer to page 10
Response time	Min.70ms
Example	BEEP1 Turns on the beeper.

Command	OUT<Boolean>
Description	Turns on or off the output.
Panel operation	Refer to page 10
Response time	Min.70ms
Example	OUT1 Turns on the output.

Command	STATUS?
Description	Returns the MODEL status.
Response time	Min.400ms
Contents	8 bits in the following format. (Refer to table on the right.)

Bit	Item	Description
0	CH1	0=CC mode, 1=CV mode
1	CH2	0=CC mode, 1=CV mode
2, 3	Tracking	01=Independent, 11=Tracking series, 10=Tracking parallel
4	Beep	0=Off, 1=On
5	N/A	N/A
6	Output	0=Off, 1=On
7	N/A	N/A

Command	SAV<NR1>
Description	Saves the panel setting.
Panel operation	Refer to page 17
NR1	1~4: Memory 1 to 4
Responses time	Min.70ms
Example	SAV1 Stores the panel setting into memory 1.

Command	RCL<NR1>
Description	Recalls a panel setting.
Panel operation	Refer to page 17
NR1	1~4: Memory 1 to 4
Responses time	Min.70ms
Example	RCL1 Recalls the panel setting stored in memory 1.

Command	*IDN?
Description	Returns the MODEL identification
Responses time	Min.300ms
Contents	Series number, firmware version

Command	HELP?
Description	Shows the command list.
Responses time	Min.1000ms
Contents	Refer to the following table.

Command	ERR?
Description	Checks the error status of the instrument and returns the nearest error message
Responses time	Min.70ms
Contents	See page 19 for list of error messages.

Contents for Command HELP	
ISet<x>:<NR2>	Sets the value of current.
VSET<x>:<NR2>	Sets the value of voltage. X: 1=CH1, 2=CH2.
ISet<x>?	Return the value of current.
VSET<x>?	Return the value of voltage.
IOUt<x>?	Returns actual output current.
VOUt<x>?	Returns actual output voltage.
TRACK<NR1>	Sets the output of the power supply working on independent or tracking mode. NR1: 0=INDE, 1=SER, 2=PARA.
BEEP<Boolean>	Sets the BEEP state on or off.
OUT<Boolean>	Sets the output state on or off
STATUS?	Returns the power supply state.
bit0:(CH1)0=CC,1=CV	
bit1:(CH2)0=CC,1=CV	
bit23:(TRACK)01=INDEP, 11=SER,10=PAR	
bit4:(BEEP)0=OFF,1=ON	
bit6:(OUT)0=OFF,1=ON	
*IDN?	Returns instrument identification.
RCL<NR0>	Recall the setting data from the memory which previous saved.
SAV<NR0>	Saves the setting data to memory.
NR0: 1=Memory1, 2=Memory2, 3=Memory3, 4=Memory4;	
ERR? Returns instrument error messages.	


6. MAINTENANCE

6.1 Inspection


- Inspect the instrument at regular intervals so that it maintains its initial performance for a long time.
- Check the input power cord for damage of the vinyl cover and overheating of the plug and cord stopper. Check the terminal screws and binding posts for loosening.
- Remove dust from the inside of the casing and ventilation holes of the cover by using a compressed air of the exhaust air of a vacuum cleaner.

6.2 Fuse Replacement

Steps 1. Take off the power cord and remove the fuse socket using a minus driver.



2. Replace the fuse in the holder.



Fuse rating 110V: T6.3A/250V
220V: T3.15A/250V

6.3 Cleaning

- Before cleaning, disconnect the AC mains.
- To clean the power supply, use a soft cloth dampened in a solution of mild detergent and water. Do not spray cleaner directly onto the instrument, since it may leak into the cabinet and cause damage.
- Do not use chemicals containing benzene, toluene, xylene, acetone, or similar solvents.
- Do not use abrasive cleaners on any portion of the instrument.

7. FAQ

Q1: I pressed the panel lock key but the output still turns on/off.

A1: The output key is not affected by the panel lock key operation, for ensuring safety.

Q2: The CH3 overload indicator turned on - is this an error?

A2: No, it simply means that the CH3 output current reached the maximum 3.0A and the operation mode turned from CV (constant voltage) to CC (constant current). You can continue using the power supply, although reducing the output load is recommended.

Q3: The specifications do not match the real accuracies.

A3: Make sure that the instrument is powered on for at least 30 minutes, within ambient temperature of +20°C ~ +30°C

Q4: The internal memory is not recording the panel setting correctly - the output should be on.

A4: The output is always stored or recalled as "off" to ensure safety.

SPECIFICATIONS (MPD-3303S)

Output ratings

CH1/CH2 independent: 0~30V, 0~3A

CH1/CH2 series: 0~60V, 0~3A

CH1/CH2 parallel: 0~30V, 0~6A

CH3: 2.5V/3.3V/5V, 3A

Constant voltage operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 3\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 5\text{mV}$ ($I > 3\text{A}$)

Recovery time: $\leq 100\mu\text{s}$ (50% load change, minimum load 0.5A)

Ripple & Noise: $\leq 1\text{mV rms}$ ($I \leq 3\text{A}$) (5Hz~1MHz) / $\leq 2\text{mV rms}$ ($I > 3\text{A}$) (5Hz~1MHz)

Temp.co-efficient: $\leq 300\text{ppm}/^\circ\text{C}$

Constant current operation

Line regulation: $\leq 0.2\% + 3\text{mA}$

Load regulation: $\leq 0.2\% + 3\text{mA}$ ($I \leq 3\text{A}$) / $\leq 0.2\% + 5\text{mA}$ ($I > 3\text{A}$)

Ripple & Noise: $\leq 3\text{mA rms}$ ($I \leq 3\text{A}$) / $\leq 6\text{mA rms}$ ($I > 3\text{A}$)

Tracking parallel operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 5\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 10\text{mV}$ ($I > 3\text{A}$)

Tracking series operation

Line regulation: $\leq 0.01\% + 5\text{mV}$

Load regulation: $\leq 300\text{mV}$

Tracking error: $\leq 0.5\% + 10\text{mV}$ of the master (No load. With load, add load regulation $\leq 300\text{mV}$)

CH3 output

Line regulation: $\leq 25\text{mV}$

Load regulation: $\leq 25\text{mV}$

Ripple & Noise: $\leq 2\text{mV rms}$

Output voltage: 2.5V, 3.3V, 5V, $\pm 8\%$

Output current: 3A

Display

Ammeter: 3.200A full scale, 4 digits 0.4" LED display

Voltmeter: 32.000V full scale, 5 digits 0.4" LED display

Voltmeter resolution: 1mV

Ammeter resolution: 1mA

Programming accuracy: $\pm(0.03\% \text{ of reading} + 10\text{mV})$ (0~30V)
($25\pm 5^\circ\text{C}$) $\pm(0.3\% \text{ of reading} + 10\text{mA})$ ($I \leq 3\text{A}$)

Readback accuracy: $\pm(0.03\% \text{ of reading} + 10\text{mV})$ (0~30V)
($25\pm 5^\circ\text{C}$) $\pm(0.3\% \text{ of reading} + 10\text{mA})$ ($I \leq 3\text{A}$)

Protection: Over load and reverse polarity protections

Insulation: Between base and output terminal $\geq 20\text{M}\Omega/500\text{VDC}$

Between base and power cord $\geq 30\text{M}\Omega/500\text{VDC}$

Operation environment: Indoor use

Altitude: $\leq 2000\text{m}$

Ambient temperature: $0\sim 40^\circ\text{C}$

Relative humidity: $\leq 80\%$

Installation category: II

Pollution degree: 2

Storage environment: Ambient temperature: $-10\sim 70^\circ\text{C}$

Relative humidity: $\leq 70\%$

Power source: AC 110V/220V $\pm 10\%$, 50/60Hz

Accessories: User manual $\times 1$, power cord $\times 1$, USB cable, USB interface software CD

Dimensions: 310(D)*250(W)*150(H)mm

Weight: 7.5kg

SPECIFICATIONS (MPD-3303/3305)

Output ratings

CH1/CH2 independent: 0~30V, 0~3A ($I \leq 3\text{A}$) / 0~30V, 0~5A ($I > 3\text{A}$)

CH1/CH2 series: 0~60V, 0~3A ($I \leq 3\text{A}$) / 0~60V, 0~5A ($I > 3\text{A}$)

CH1/CH2 parallel: 0~30V, 0~6A ($I \leq 3\text{A}$) / 0~30V, 0~10A ($I > 3\text{A}$)

CH3: 2.5V/3.3V/5V, 3A

Constant voltage operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 3\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 5\text{mV}$ ($I > 3\text{A}$)

Recovery time: $\leq 100\mu\text{s}$ (50% load change, minimum load 0.5A)

Ripple & Noise: $\leq 1\text{mV rms}$ ($I \leq 3\text{A}$) (5Hz~1MHz) / $\leq 2\text{mV rms}$ ($I > 3\text{A}$) (5Hz~1MHz)

Temp.co-efficient: $\leq 300\text{ppm}/^\circ\text{C}$

Constant current operation

Line regulation: $\leq 0.2\% + 3\text{mA}$

Load regulation: $\leq 0.2\% + 3\text{mA}$ ($I \leq 3\text{A}$) / $\leq 0.2\% + 5\text{mA}$ ($I > 3\text{A}$)

Ripple & Noise: $\leq 3\text{mA rms}$ ($I \leq 3\text{A}$) / $\leq 6\text{mA rms}$ ($I > 3\text{A}$)

Tracking parallel operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 5\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 10\text{mV}$ ($I > 3\text{A}$)

Tracking series operation

Line regulation: $\leq 0.01\% + 5\text{mV}$

Load regulation: $\leq 300\text{mV}$

Tracking error: $\leq 0.5\% + 50\text{mV}$ of the master (No load. With load, add load regulation $\leq 300\text{mV}$)

CH3 output

Line regulation: $\leq 25\text{mV}$

Load regulation: $\leq 25\text{mV}$

Ripple & Noise: $\leq 2\text{mV rms}$

Output voltage: 2.5V, 3.3V, 5V, $\pm 8\%$

Output current: 3A

Display

Ammeter: 3.20A full scale, 3 digits 0.5" LED display (MPD-3303)

5.10A full scale, 3 digits 0.5" LED display (MPD-3305)

Voltmeter: 32.0V full scale, 3 digits 0.5" LED display

Voltmeter resolution: 10mV(0~9.99V), 100mV(10~30V)

Ammeter resolution: 10mA

Programming accuracy: $\pm(0.2\%$ of reading + 3digits) (0~9.99V)

($25 \pm 5^\circ\text{C}$) $\pm(0.5\%$ of reading + 2digits) (10~30V)

$\pm(0.5\%$ of reading + 2digits) ($I \leq 3\text{A}$)

$\pm(0.5\%$ of reading + 5digits) ($I > 3\text{A}$)

Readback accuracy: $\pm(0.2\%$ of reading + 3digits) (0~9.99V)

($25 \pm 5^\circ\text{C}$) $\pm(0.5\%$ of reading + 2digits) (10~30V)

$\pm(0.5\%$ of reading + 3digits) ($I \leq 3\text{A}$)

$\pm(0.5\%$ of reading + 5digits) ($I > 3\text{A}$)

Protection: Over load and reverse polarity protections

Insulation: Between base and output terminal $\geq 20\text{M}\Omega/500\text{VDC}$

Between base and power cord $\geq 30\text{M}\Omega/500\text{VDC}$

Operation environment: Indoor use

Altitude: $\leq 2000\text{m}$

Ambient temperature: 0~40 $^\circ\text{C}$

Relative humidity: $\leq 80\%$

Installation category: II

Pollution degree: 2

Storage environment: Ambient temperature: $-10\sim 70^{\circ}\text{C}$

Relative humidity: $\leq 70\%$

Power source: AC 110V/220V $\pm 10\%$, 50/60Hz

Accessories: User manual $\times 1$, power cord $\times 1$

Dimensions: 310(D)*250(W)*150(H)mm

Weight: 7.5kg (MPD-3303) / 10kg (MPD-3305)

SPECIFICATIONS (MPD-3303D/3305D)

Output ratings

CH1/CH2 independent: 0~30V, 0~3A ($I \leq 3\text{A}$) / 0~30V, 0~5A ($I > 3\text{A}$)

CH1/CH2 series: 0~60V, 0~3A ($I \leq 3\text{A}$) / 0~60V, 0~5A ($I > 3\text{A}$)

CH1/CH2 parallel: 0~30V, 0~6A ($I \leq 3\text{A}$) / 0~30V, 0~10A ($I > 3\text{A}$)

CH3: 2.5V/3.3V/5V, 3A

Constant voltage operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 3\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 5\text{mV}$ ($I > 3\text{A}$)

Recovery time: $\leq 100\mu\text{s}$ (50% load change, minimum load 0.5A)

Ripple & Noise: $\leq 1\text{mV rms}$ ($I \leq 3\text{A}$) (5Hz~1MHz) / $\leq 2\text{mV rms}$ ($I > 3\text{A}$) (5Hz~1MHz)

Temp.co-efficient: $\leq 300\text{ppm}/^{\circ}\text{C}$

Constant current operation

Line regulation: $\leq 0.2\% + 3\text{mA}$

Load regulation: $\leq 0.2\% + 3\text{mA}$ ($I \leq 3\text{A}$) / $\leq 0.2\% + 5\text{mA}$ ($I > 3\text{A}$)

Ripple & Noise: $\leq 3\text{mA rms}$ ($I \leq 3\text{A}$) / $\leq 6\text{mA rms}$ ($I > 3\text{A}$)

Tracking parallel operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 5\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 10\text{mV}$ ($I > 3\text{A}$)

Tracking series operation

Line regulation: $\leq 0.01\% + 5\text{mV}$

Load regulation: $\leq 300\text{mV}$

Tracking error: $\leq 0.5\% + 50\text{mV}$ of the master (No load. With load, add load regulation $\leq 300\text{mV}$)

CH3 output

Line regulation: $\leq 25\text{mV}$

Load regulation: $\leq 25\text{mV}$

Ripple & Noise: $\leq 2\text{mV rms}$

Output voltage: 2.5V, 3.3V, 5V, $\pm 8\%$

Output current: 3A

Display

Ammeter: 3.20A full scale, 3 digits 0.5" LED display (MPD-3303D)

5.10A full scale, 3 digits 0.5" LED display (MPD-3305D)

Voltmeter: 32.0V full scale, 3 digits 0.5" LED display

Voltmeter resolution: 100mV

Ammeter resolution: 10mA

Programming accuracy: $\pm(0.5\% \text{ of reading} + 2\text{digits})(0\sim 30\text{V})$,
($25\pm 5^\circ\text{C}$) $\pm(0.5\% \text{ of reading} + 2\text{digits}) (I\leq 3\text{A})$
 $\pm(0.5\% \text{ of reading} + 5\text{digits}) (I>3\text{A})$

Readback accuracy: $\pm(0.5\% \text{ of reading} + 2\text{digits})(0\sim 30\text{V})$,
($25\pm 5^\circ\text{C}$) $\pm(0.5\% \text{ of reading} + 3\text{digits}) (I\leq 3\text{A})$
 $\pm(0.5\% \text{ of reading} + 5\text{digits}) (I>3\text{A})$

Protection: Over load and reverse polarity protections

Insulation: Between base and output terminal $\geq 20\text{M}\Omega/500\text{VDC}$

Between base and power cord $\geq 30\text{M}\Omega/500\text{VDC}$

Operation environment: Indoor use

Altitude: $\leq 2000\text{m}$

Ambient temperature: $0\sim 40^\circ\text{C}$

Relative humidity: $\leq 80\%$

Installation category: II

Pollution degree: 2

Storage environment: Ambient temperature: $-10\sim 70^\circ\text{C}$

Relative humidity: $\leq 70\%$

Power source: AC 110V/220V $\pm 10\%$, 50/60Hz

Accessories: User manual $\times 1$, power cord $\times 1$, USB cable, USB interface software CD

Dimensions: 310(D)*250(W)*150(H)mm

Weight: 7.5kg (MPD-3303D) / 10kg (MPD-3305D)

SPECIFICATIONS (MPD-3303C/3305C)

Output ratings

CH1/CH2 independent: $0\sim 30\text{V}$, $0\sim 3\text{A}$ ($I\leq 3\text{A}$) / $0\sim 30\text{V}$, $0\sim 5\text{A}$ ($I>3\text{A}$)

CH1/CH2 series: $0\sim 60\text{V}$, $0\sim 3\text{A}$ ($I\leq 3\text{A}$) / $0\sim 60\text{V}$, $0\sim 5\text{A}$ ($I>3\text{A}$)

CH1/CH2 parallel: $0\sim 30\text{V}$, $0\sim 6\text{A}$ ($I\leq 3\text{A}$) / $0\sim 30\text{V}$, $0\sim 10\text{A}$ ($I>3\text{A}$)

CH3: 2.5V/3.3V/5V, 3A

Constant voltage operation

Line regulation: $\leq 0.01\% + 3\text{mV}$

Load regulation: $\leq 0.01\% + 3\text{mV}$ ($I\leq 3\text{A}$) / $\leq 0.02\% + 5\text{mV}$ ($I>3\text{A}$)

Recovery time: $\leq 100\mu\text{s}$ (50% load change, minimum load 0.5A)

Ripple & Noise: $\leq 1\text{mV rms}$ ($I\leq 3\text{A}$) (5Hz~1MHz) / $\leq 2\text{mV rms}$ ($I>3\text{A}$) (5Hz~1MHz)

Temp.co-efficient: $\leq 300\text{ppm}/^\circ\text{C}$

Constant current operation

Line regulation: $\leq 0.2\% + 3\text{mA}$
Load regulation: $\leq 0.2\% + 3\text{mA}$ ($I \leq 3\text{A}$) / $\leq 0.2\% + 5\text{mA}$ ($I > 3\text{A}$)
Ripple & Noise: $\leq 3\text{mA rms}$ ($I \leq 3\text{A}$) / $\leq 6\text{mA rms}$ ($I > 3\text{A}$)

Tracking parallel operation

Line regulation: $\leq 0.01\% + 3\text{mV}$
Load regulation: $\leq 0.01\% + 5\text{mV}$ ($I \leq 3\text{A}$) / $\leq 0.02\% + 10\text{mV}$ ($I > 3\text{A}$)

Tracking series operation

Line regulation: $\leq 0.01\% + 5\text{mV}$
Load regulation: $\leq 300\text{mV}$
Tracking error: $\leq 0.5\% + 100\text{mV}$ of the master (No load. With load, add load regulation $\leq 300\text{mV}$)

CH3 output

Line regulation: $\leq 25\text{mV}$
Load regulation: $\leq 25\text{mV}$
Ripple & Noise: $\leq 2\text{mV rms}$
Output voltage: 2.5V, 3.3V, 5V, $\pm 8\%$
Output current: 3A

Display

Ammeter: 3.20A full scale, 3 digits 0.5" LED display (MPD-3303C)
5.10A full scale, 3 digits 0.5" LED display (MPD-3305C)
Voltmeter: 32.0V full scale, 3 digits 0.5" LED display
Voltmeter resolution: 100mV
Ammeter resolution: 10mA
Programming accuracy: $\pm(0.5\% \text{ of reading} + 2\text{digits})(0 \sim 30\text{V})$,
($25 \pm 5^\circ\text{C}$) $\pm(0.5\% \text{ of reading} + 2\text{digits})$ ($I \leq 3\text{A}$)
 $\pm(0.5\% \text{ of reading} + 5\text{digits})$ ($I > 3\text{A}$)

Readback accuracy: $\pm(0.5\% \text{ of reading} + 2\text{digits})(0 \sim 30\text{V})$,
($25 \pm 5^\circ\text{C}$) $\pm(0.5\% \text{ of reading} + 3\text{digits})$ ($I \leq 3\text{A}$)
 $\pm(0.5\% \text{ of reading} + 5\text{digits})$ ($I > 3\text{A}$)

Protection: Over load and reverse polarity protections

Insulation: Between base and output terminal $\geq 20\text{M}\Omega/500\text{VDC}$
Between base and power cord $\geq 30\text{M}\Omega/500\text{VDC}$

Operation environment: Indoor use

Altitude: $\leq 2000\text{m}$
Ambient temperature: $0 \sim 40^\circ\text{C}$
Relative humidity: $\leq 80\%$
Installation category: II
Pollution degree: 2

Storage environment: Ambient temperature: $-10 \sim 70^\circ\text{C}$
Relative humidity: $\leq 70\%$

Power source: AC 110V/220V $\pm 10\%$, 50/60Hz

Accessories: User manual×1, power cord×1, USB cable, USB interface software CD


Dimensions: 310(D)*250(W)*150(H)mm

Weight: 7.5kg (MPD-3303C) / 10kg (MPD-3305C)

Apéndice C

Manuales de los instrumentos

C.2 Carga electrónica Array 3710A, Manual de usuario



PROGRAMMABLE DC ELECTRONIC LOAD

3700 SERIES user's manual



VERSION 2.0 2006 .03

SAFETY GUIDE

This manual contains the precautions necessary to ensure your personal safety as well as for protection for the products and the connected equipment. These precautions are highlighted with a triangle “**WARNING**” symbol in this manual and are marked according to the danger levels as follows:



Danger:

It indicates that if appropriate precautions are not taken, serious incidents of personal injuries and deaths or significant damages or losses to the properties will be caused.



Caution:

It indicates that if appropriate precautions are not taken, injuries or losses of properties will take place.



Note:

Remind you to pay particular attention to the important information related to the products, disposal of products or the specific part of documents.



Warning:

Only qualified personnel are allowed to debug and operate this equipment. The qualified personnel are specified as those personnel who carry out commissioning, grounding and apply the volume identification to the circuits, equipment and systems according to the available safety practices and standards.



Note:

Only when this product is transported, stored assembled and installed in a proper way and operated and maintained according to the recommendations, can it implement the functions properly and reliably.

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. The manufacturer assumes no liability for the customer's failure to comply with these requirements.



Attention

I. Safety

1. Users should operate according to this manual.
2. There is high voltage inside the instrument, please avoid touching it directly.
3. Please read the user manual carefully before you use the instrument to assure your safety.
4. Ground the Instrument

This product is provided with a protective earth terminal. To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument must be connected to the AC power supply mains through a three-conductor power cable, with the third wire firmly connected to an electrical ground (safety ground) at the power outlet.

5.Keep Away From Live Circuits

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified service person. Do not split the components when power cable connected.

Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power, discharge circuits and remove external voltage sources before touching components.

6.Do Not Substitute Parts or Modify Instrument

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to a qualified dealer for service and repair to ensure that safety features are maintained.

II. Connecting the power line

1. Inspect the power selection switch on the back panel, to assure if the selected voltage is the same as environment power voltage. If not, please refer to the notice around the power plug.
2. Before connecting the power supply, please be sure that the switch on the front panel should be in the off position.
3. Connect the power cable to the AC in the power supply and the 3 connector plug. Please be sure that the AC power supply is grounded.
4. Press the switch on the front panel to switch on the instrument and you can start to use it.

III. Fuse

1. The fuse is at the position of power input part on the back panel, for the purpose of avoiding failure brought by using wrong voltage. Please pay attention to the following items when you change the voltage input and the fuse.
2. Before changing the voltage and fuse, please be sure that the AC power is switching off, and be sure that there is no other equipment connected to this instrument.
3. Put a screwdriver into the fuse mounting, press it and the fuse mounting will pop up.
4. Pull out the fuse, change it according to the label beside the power input plug.

Warning: To avoid damaging the instrument, please be sure to change a suitable type fuse.

3700 SERIES USER MANUAL

Programmable DC Electronic Load

3700 SERIES

Table of Contents

PART1:3700 Series Electronic Load

Chapter 1 General Introduction.....	1
1.1 General Introduction.....	1
1.2 Specification.....	1
1.3 Features.....	2
1.4 Dimension and Structure.....	2
1.4.1 Dimension.....	2
1.4.2 Structure.....	3
1.4.2.1 Front view.....	3
1.4.2.2 Back view.....	4
Chapter 2 Operation.....	5
2.1 Connect the power supply to the electronic load.....	5
2.2 Main functions.....	5
2.2.1 Constant Current Mode.....	5
2.2.2 Constant Power Mode.....	7
2.2.3 Constant Resistance Mode.....	7
2.2.4 Store a program.....	8
2.2.5 Recall a program.....	9
2.2.6 Start a program.....	9
2.2.7 Stop a program.....	9
2.2.8 Load On/Off.....	9
2.3 Menu operation.....	9
2.3.1 Setting the maximum current.....	10
2.3.2 Setting the maximum power.....	10
2.3.3 Setting Minimum Input Voltage.....	10
2.3.4 Setting Baud Rate.....	10
2.3.5 Setting Address (0~254).....	10
2.3.6 Enable / disable the Rotary knob.....	11
2.3.7 Program.....	11
2.3.8 Save option.....	12
2.3.9 Lock the keyboard.....	13
2.3.10 Load Default.....	13
2.3.11 Exit.....	13

3700 SERIES USER MANUAL

PART 2: Electronic Load Software.....	14
Chapter 1 Software Installation.....	15
1.1 Connect the electronic load to PC.....	15
1.2 Installation.....	15
Chapter 2 Introduction.....	19
2.1 Running the program.....	19
2.2 The Eload List.....	20
2.3 The Eload Mode List.....	20
2.4 Control Switch.....	20
2.5 The Tool Buttons.....	21
2.6 Keypad and Rotary dial.....	21
2.7 The Amp, Power, Resistance, Voltage Meter.....	22
2.8 Dynamic Curve.....	22
2.9 Setting.....	23
2.10 Programming Window.....	24
2.11 Eload Setting.....	24
2.12 Data Report.....	26
2.13 Use Electronicload software control your load.....	27
Chapter 3 Uninstall ElectronicLoad Software.....	28
3.1 Uninstall the ElectronicLoad Software.....	28

Chapter 1 General Introduction

1.1 General Introduction

Array 3700 series electronic load is a single input programmable DC electronic load. It provides a convenient way to test DC power supplies and batteries. It offers constant current mode, constant resistance mode and constant power mode. Program operation and control by PC is also available. The backlight LCD, numerical keypad and rotary knob make it much easier to use. It is an essential instrument for designing, testing and manufacturing of many suitable products.

1.2 Specifications

Model	3710A	3711A
Number of Input	1	1
Input Voltage	0~360V	0~360V
Input Power	0~150W	0~300W
Input Current	0~30A	0~30A
Voltage Accuracy	0.000-3.999V: $\pm 0.2\%+3\text{mV}$ 4.00-35.999V $\pm 0.2\%+30\text{mV}$ 36.0-360.0V: $\pm 0.2\%+300\text{mV}$	
Current Accuracy	0.000-2.999A: $\pm 0.2\%+3\text{mA}$ 3.00-30.00: $\pm 0.2\%+30\text{mA}$	
Max Resolution	Voltage: 1mV Current: 1mA	
Minimum Conductive Resistance	< 0.08	
Ripple	< 10mVpp	
Communication Interface	RS232/RS485 /USB*	
Software	Free application software ElectronicLoad, ActiveX control support VC++ / VB / DELPHI / LABVIEW	
Program Memory	9 programs, 10 steps each	
Protective Mode	Over voltage/over current/over power/over heat/polarity-reverse	
AC Input	110/220V AC switch able (60/50HZ)	
Weight	5.0kg	
Accessories	Software, users manual, AC power cable, handlebars	
Optional Parts	3311 isolated TTL to RS232 adaptor 3312 isolated TTL to USB adaptor 3313 isolated RS232 to RS485 adaptor 3314 isolated TTL to RS485 adaptor Mounting rack	

3700 SERIES USER MANUAL

1.3 Features

1. LCD display with backlight.
2. High resolution measurement.
3. CC/CP/CR mode.
4. Number keypad and rotary knob.
5. Multifunction menu.
6. Over voltage / over current / over power / over temperature / polarity reversion protection.
7. 10 steps program.
8. Compact and light-weight.
9. Can be used in parallel connection.
10. Can be controlled by PC.

1.4 Dimensions and Structure

1.4.1 Dimensions (unit: mm)




Fig.1-1 Dimension of 3700 Series Programmable DC electronic load

1.4.2 Structure

1.4.2.1 Front view

Front panel is for users to operate, and there is one LCD display, one number keypad and one rotary knob. Please see the following pictures.



Fig.1-2 Front view of 3700 Series DC electronic load

1. LCD display




Fig.1-3 LCD Display of 3700 Series electronic load

The 1st line:

Current, voltage, On/Off state

The 2nd line:

Power, load setting value, working mode.

CC, CP, CR represent constant current, constant power, constant resistance mode.

2. Arrangement of the Keyboard

In general, the keyboard will perform the function of the black words 1st. But in the 2nd mode, it will perform the function of the words in blue.




Fig.1-4 Keyboard of 3700 Series DC electronic load

0~9: The number keys

Load on/off: Load ON/OFF switch

R-set: Setting resistance value

I-set: Setting current value

P-set: Setting power value

Store: Store current program

Recall: Recall a saved program

Start: Start a program

Stop: Stop running program

Menu: Menu function operation

▲: The up moving key

▼: The down moving key

3. Rotary knob and function keys



Fig.1-5 Rotary knob and function keys

◀ : The left moving key

▶ : The right moving key

ESC: Escape key

OK: Confirmation key

Rotary knob: The rotation dial

1.4.2.2 Back view




Fig.1-6 Back view

The fuse can be changed easily by using a small flat screw driver. Please use a fuse within the range of 0.3-0.5A.

Chapter 2 Operation

2.1 Connect the power supply to the electronic load



Fig.2-1 Connect the power supply to the electronic load

2.2 Main functions

1. Constant current mode
2. Constant power mode
3. Constant resistance mode
4. Store a program
5. Recall a program
6. Start a program
7. Stop a program
8. Load On/Off

2.2.1 Constant Current Mode

In constant current mode, the electronic load will sink a constant current in accordance with the set value regardless of input voltage. The current value can be set with the keyboard and/or rotary knob. Please see the following operation procedure:

3700 SERIES USER MANUAL

Constant current setting procedure:

Procedure	Operation details	LCD display
Step 1	Press “I-set”	Input Password
Step 2	Enter the password (if the keyboard isn’t locked, please go to step4)	Input Password ****
Step 3	Press the “OK” button, the original set value will be displayed on the LCD. (It will return to step 2 if your password is wrong)	Set Curr = 2.00A New=
Step 4	Enter the new current value with the number keypad or rotate the dial to adjust the value	Set Curr = 2.00A New= 3.00
Step 5	Press “I-set” button for confirmation	Set Curr =3.00A New= 3.00
Step 6	Press ESC to go back to the main menu	
You can exit the current set operation at any point by pressing the ESC key		

For example, set constant current to 3.12A

1. Setting by number keyboard

Step1. Press “I-set” button,

Step2. Enter the password by using the number keyboard (if the keyboard isn’t locked, please go to step4),

Step3. Press “OK” button (if the password is wrong, please go to step2 for reentering),

Step4. Press “3”, “.”, “1” and “2” button to enter the current value,

Step5. Press “I-set” button to confirm the current value.

0.000A	0.000V	OF
0.0W	3.12A	CC

2. Setting by Rotary Knob

(1) If the keyboard isn’t locked, press “I-set” button, then directly rotate the “Rotary knob”, the current value will be continually changed from the previous value according to the rotation. At the beginning, the cursor will be shown on the last number of the value which is indicated on the LCD, you can move the cursor to the first number, second number etc by using “◀” and “▶” buttons, and then rotate to change each number, and let it stay at 3.12 A.

(2) If the keyboard is locked

Step1. Press “ I-set ” button,

Step2. Enter the password by using the number keyboard,

Step3. Press OK button (if the password is wrong, please go to step2 for reentering),

Step4. Rotate the Rotary to change the value , the operation is the same as item (1)

Step5. Press “ I-set ” button to confirm the current value.

2.2.2 Constant Power Mode

In constant power mode, the load's current will increase automatically if the input voltage is decreased or vice versa, so that the electronic load will sink a constant power in accordance with the set value. The power value can be set with the keyboard and/or rotary knob. Please see the following operation procedure:

Constant power setting procedure:

Procedure	Operation details	LCD display
Step 1	Press “P-set”	Input Password
Step 2	Enter the password (if the keyboard isn't locked, please go to step4)	Input Password ****
Step 3	Press the “OK ” button, the original set value will be displayed on the LCD. (It will return to step 2 if your password is wrong)	Set Power = 20.0W New=
Step 4	Enter the new power value with the number keypad or rotate the dial to adjust the value	Set Power = 20.0W New= 30.0
Step 5	Press “P-set” button for confirmation	Set Power = 30.0W New= 30.0
Step 6	Press ESC to go back to the main menu	
You can exit the power set operation at any point by pressing the ESC key		

2.2.3 Constant Resistance Mode

In constant resistance mode, the electronic load will sink a current linearly proportional to the input voltage in accordance with the set value. The resistance value can be set with the keyboard and/or rotary knob. Please see the following operation procedure:

3700 SERIES USER MANUAL

Constant resistance setting procedure:

Procedure	Operation details	LCD display
Step 1	Press “R-set” button	Input Password
Step 2	Enter the password (if the keyboard isn’t locked, please go to step4)	Input Password ****
Step 3	Press the “OK ” button, the original set value will be displayed on the LCD. (It will return to step 2 if your password is wrong)	Set Resis = 200.0 New=
Step 4	Enter the new resistance value with the number keypad or rotate the dial to adjust the value	Set Resis = 200.0 New= 50.00
Step 5	Press “R-set” button for confirmation	Set Resis = 50.00 New= 50.00
Step 6	Press ESC to go back to the main menu	
You can exit the resistance set operation at any point by pressing the ESC key		

2.2.4 Store a program

The 3700 Series electronic load provides a program mode for dynamic testing. The user can program the 3700 series electronic load and define the load values (current, power, resistance) and duration of every step. For more details about the programming operation, please refer to 2.3.7.

User’s program may be stored in the 3700’s nonvolatile memory for later use. Up to 9 programs can be stored in the 3700. To store a program, please follow this operation procedure:

Procedure	Operation details	LCD display
Step1	Press “ Store ” button	SAVE 1
Step 2	Enter the program number (1 to 9) by using the number key or the rotary knob	SAVE *
Step 3	Press the “ OK ” button for confirmation. It will return to Step 2 if the number is out of the range.	
You can exit the store operation at any point by pressing the ESC key		

2.2.5 Recall a program

To recall a program stored in the 3700, please follow this operation procedure:

Procedure	Operation details	LCD display
Step1	Press “ Recall ” button	RECALL 1
Step 2	Enter the program number (1 to 9) by using the number key or the rotary knob	RECALL *
Step 3	Press the “ OK ” button for confirmation. It will return to Step 2 if the number is out of the range.	
You can exit the recall operation at any point by pressing the ESC key		

2.2.6 Start a program

Press “Start” button to run the current program.

2.2.7 Stop a program

Press “Stop” button to stop the running program.

2.2.8 Load On/Off

The load’s input can be toggled on/off through the Load On/Off key.

2.3 Menu operation

The Menu operation offers some setting and adjusting functions. The operation and functions are as following.

Procedure	Operation details	LCD display
Step1	Press “ Menu ” button	
Step 2	The LCD displays the menu functions. Use the UP and DOWN keys to select a function, then press “ OK ” for confirmation	Maximum Current Maximum Power Min Input Volt Band Rate Address Knob Enable Program Save Option Key Lock Load Default Exit
You can exit the menu operation at any point by pressing the ESC key		

2.3.1 Setting the maximum current

When you select the Maximum Current function, the LCD will display:

Max Curr=**A**
New=

Set the maximum current value by using the number keyboard or the rotary knob, then press “OK” for confirmation.

2.3.2 Setting the maximum power

When you select the Maximum Power function, the LCD will display:

Max Power=**W**
New=

Set the maximum power value by using the number keyboard or the rotary knob, then press “OK” for confirmation.

2.3.3 Setting Minimum Input Voltage

This function is used to set the minimum input voltage, when the input voltage is lower than this value, the 3700 electronic load will automatically stop. This function is used to discharge batteries. When the battery’s voltage drops down to the set value, the load switches off automatically, keeping the battery from over-discharge. When you select Min Input Volt function, the LCD will display:

Min Volt=**V**
New=

Set the minimum input voltage by using the number keyboard or the rotary knob, then press “OK” for confirmation.

2.3.4 Setting Baud Rate

This function is used to set the communication baud rate.

When you select the Baud Rate function, the LCD will display:

4800 bps
9600 bps
19200 bps
38400 bps Def*

Select the Baud Rate by using the UP and DOWN keys or the rotary knob, then press “OK” for confirmation.

2.3.5 Setting Address (0~254)

This function is used to set the address of the load. To communicate with the computer or other equipment, the 3700 load must be assigned an address.

When you select Address set function, the LCD will display:

Set Address=***
New=

Set the address by using the number keyboard or the rotary knob, and then press “OK” for confirmation. The valid address range is from 0 to 254.

2.3.6 Enable/disable the Rotary knob

This function is to enable or disable the rotary knob.

Enable Def. *

Disable

Use the UP and DOWN keys or rotary knob to select, and press “OK” to confirm.

2.3.7 Program

3700 Series electronic load provides a program mode for dynamic testing. The user can program the 3700 series electronic load and define the load values (current, power, resistance) and duration of each program step. To program the 3700, please follow these 4 steps:

- 1、 Select one working mode: constant current, constant power, constant resistance;
- 2、 Set the length of the program;
- 3、 Set the load value (current, power, or resistance value) and duration time of each step;
- 4、 Select program running mode: one time or repeat.

For example, you need to set the following program:

Constant Current mode:

Step1 1A for 2 seconds

Step2 2A for 5 seconds

Step3 3A for 10 seconds

Repeat running step1 to step3.

Programming procedure is showed below:

- 1、 Select Program Set from menu operation, the LCD will display:

Constant Curr

Constant Power

Constant Resis

Use the UP and DOWN keys or rotary knob to select Constant Current mode, and press “OK” to confirm.

- 2、 LCD will display:

Step Number=*

New=

Input the program length “3” and press “OK” to confirm.

- 3、 LCD will display:

Step1 Set=0.00

New=

Input the current value “1” A, then press “OK” to confirm.

3700 SERIES USER MANUAL

4、 LCD will display:

Step Time=1s

New=

Input the time value “2”s, then press “OK” to confirm.

5、 LCD will display:

Step 2 Set=0.00

New=

Input the current value “2” A, then press “OK” to confirm.

6、 LCD will display:

Step Time=1s

New=

Input the time value “5”s, then press “OK” to confirm.

7、 LCD will display:

Step 3 Set=0.00

New=

Input the current value “3” A, then press “OK” to confirm

8、 LCD will display:

Step Time=1s

New=

Input the time value “10”s, then press “OK” to confirm.

9、 LCD will display:

One Time

Repeat

Select Repeat, then press “OK” to confirm.

The programming process is completed. Press “ESC” to return to the main menu, press “Start” to run the program.
If you want to store this program for later use, please see 2.2.4

2.3.8 Save Option

This function is used to save the last load setting (current, power and resistance) before switching off the 3700. When this option has been set, every time the user switches on the 3700, the previous load setting will be restored automatically.

Select the Save Option function, the LCD will display:

Save I,P,R

Don't Save Def*

Use the UP and DOWN keys or the rotary knob to change the selection, then press “OK” to confirm. Select Save I, P, R, and load setting will be saved before the unit is switched off, and will be restored automatically when switched on the next time. Select Don't Save def* represent not to save current load setting.

2.3.9 Lock the keyboard

This function is used to lock the keyboard, keep the load setting from unauthorized change. Only the person with correct password is allowed to operate the 3700.

Select the Key Lock function, the LCD will display:

Set Password

Enter a 4 numbers password, then press “OK ” to confirm.

2.3.10 Load Default

This function is used to restore all the parameters to the factory setting.

Select Load Default function, LCD will display:

Don't Load

Load Default

Select Load Default, and press “OK” to restore to the factory setting.

2.3.11 Exit

Select “Exit” to exit the menu operation.

ElectronicLoad Software

ElectronicLoad is a free software which allow the user to monitor and control the Array 3700 series electronic load.

Chapter 1 Software Installation

1.1 Connect the electronic load to PC

With the optional communication adapter, you can connect the 3700 load to your computer through RS-232, USB or RS-485 port. Connect the 3700 to a RS-232 port with the 3311 adapter, to a USB port with the 3312, to a RS-485 with the 3314. If your computer doesn't have an RS-485 port, you may choose the 3313 RS-232=>RS-485 adapter.



Fig.1-1 Connect the electronic load to PC

1.2 Installation

1.2.1 Insert the Array software CD into the CD-ROM drive, double-click My Computer => Array CD => Eload => Setup.exe to start the installation, the Fig. 1-2 will be displayed.




Fig.1-2 The Initialization of the Installation

3700 SERIES USER MANUAL

1.2.2 The Welcome dialog box displays, press “ NEXT ” to continue




Fig.1-3 The Welcome dialog box

1.2.3 The License Agreement dialog box displays. Click Yes to accept the License Agreement and proceed with the installation process.

Note: If you do not want to accept the License Agreement, click No to abort the installation process.




Fig.1-4 The License Agreement dialog box

1.2.4 The User Information dialog box displays, Enter your name and your company's name, then click Next.



Fig.1-5 The User Information dialog box

- 1.2.5 The destination folder dialog box displays. The default folder is “C:\Program Files\Array\ELoad”. You may click “Browse” to select other installation path.




Fig.1-6 The destination folder dialog box

- 1.2.6 The installation option dialog box displays. Select “Typical” to install all components or select “Custom” to select installation components.



Fig.1-7 The installation option dialog box

- 1.2.7 The Select Program Folder dialog box displays. Specify a program folder (or leave the default folder), then click Next.



Fig.1-8 The Select Program Folder dialog box

1.2.8 Copy the files to your hard disk.



Fig.1-9 Copy Files

Software installation is complete when finished.

Chapter 2 Introduction

2.1 Running the program

2.1.1 To run the ElectronicLoad program, select “Start=>Program=>Array=>Eload” and click “E3710A” or E3711A” to run the program.




Fig.2-1 Start the program

2.1.2 The ElectronicLoad startup pattern



Fig.2-2 ElectronicLoad Startup pattern

3700 SERIES USER MANUAL

2.1.3 The ElectronicLoad Main Window




Fig.2-3 The ElectronicLoad Main Window

2.2 The ELoad List

The Eload list lists all registered electronic load on the computer. To make the ElectronicLoad control your load, choose the load you want to use from the Eload list.




Fig.2-4 The Eload List

2.3 The Load Mode List

From the Load Mode list, you can select Load Mode: Constant Current, Constant Power, Constant Resistance.



Fig.2-5 The Load Mode List

2.4 Control Switch

The Load On/Off switch is to turn on/off the electronic load; the Self/PC Control switch is to set who control the electronic load: the PC or the load itself.













Fig.2-6 Control switch

2.5 The Tool Buttons

On the top left of the main window, there are 9 tool buttons:

-  “Start”: Start communication
-  “Stop”: Stop communication
-  “Setting”: setting COM Port and recording interval
-  “Program”: Setting a Program
-  “Run Program”: Run a Program
-  “Stop Program”: Stop Running Program
-  “Eload Setting”: Setting load parameters
-  “Report”: Data report
-  “Quit”: Quit the ElectronicLoad program

2.6 Keypad and Rotary dial:



Fig.2-7 Current, Power, Resistance setting dial

To quickly modify a parameter (Current, Power, Resistance), put the mouse on the red point of the dial and rotate. To accurately set a parameter, use the keypad.




Fig.2-8 Keypad

3700 SERIES USER MANUAL

Set Current: Press “I set”, input the current value (0~30A), press “ENTER” to confirm.

Set Power: Press “P set”, input the power value (3710A: 0~150W, 3711A: 0~300W), press “ENTER” to confirm.

Set Resistance: Press “R set”, input the resistance value (0~500Ω), press “ENTER” to confirm.

I Max, P Max, R Max: show the max value of each parameter.

2.7 The Amp, Power, Resistance, Voltage Meter

The Amp, Power, Resistance, Voltage Meter show the setting and read back value of current, power, resistance and voltage.




Fig.2-9 The Amp, Power, Resistance, Voltage Meter

2.8 Dynamic Curve

These curve show the dynamic states of voltage and current.




Fig.2-10 The Voltage Curve





Fig.2-11 The Current Curve

You may drag your mouse on the curve to zoom in/out.

2.9 Setting

2.9.1 Setting Com port and baud rate

Click the  button, select the correct Com port and baud rate. The baud rate setting should be the same as the connected electronic load.




Fig.2-12 Setting Window

2.9.2 Setting electronic load address




Fig.2-13 Address Setting window

Click “Address” to go to the Address setting window. Set an address that is the same as the connected electronic load. Press “OK” to confirm.

2.9.3 Setting Recording Interval




Fig.2-14 Setting Recording Interval window

3700 SERIES USER MANUAL

2.10 Programming Window:

ElectronicLoad allows user to make an own program to control the 3700 load. User can select the load mode, and define load value (current, power, resistance) and duration of each program step.

Click the  button, the Program window will be displayed:






Fig.2-15 Programming window

Select an “Electronic Load Mode”; enter the load value and the duration of each program step.


The maximum program length is 10 steps. But user may decided only run part of them. Use the “Run Steps” push bar to decide how many steps you want to run.

Program State is used to define whether repeat to run this program.

When finishing, press “OK” to store the program and go back to the main window.

Press  button to run the program; press  button to stop the program.

2.11 Eload setting

Click the  button, the Eload setting window will be displayed.






Fig.2-16 The Eload Setting window

The Eload Registration Records show the parameters of all registered load.

To add a new load, click the  button.



The dialog box titled 'Add/Modify' contains a section titled 'ELoad Parameters'. It has six input fields: 'ELoad ID' (text box with '1'), 'ELoad Name' (text box with 'E3710A'), 'ELoad Address' (spin box with '5'), 'Max Current(A)' (text box with '30'), 'Max Power(W)' (text box with '200'), and 'Max Resistance(Ω)' (text box with '500'). At the bottom are 'OK' and 'Cancel' buttons.

Fig.2-17 Add new load window


Enter the Eload Name, Address and the maximum value of current, power, resistance, then press “OK” to confirm.


Note: the Eload ID is assigned by the software.

The Parameter Explanation

Parameter	Explanation	Range
Eload ID	ID	
Eload Name	Name	ASCII
Eload Address	Address	0-254
Max Current	Maximum Current	0-30A
Max Power	Maximum Power	0-150W /300W
Max Resistance	Maximum Resistance	0-500

To delete a registered load, select the load from the Eload Registration Records, then click the  button.

To modify a load's parameters, select the load from the Eload Registration Records, then click the  button.

To query a load, click the  button, then enter the load name you want to query.

Attention: after the Add, Modify, Delete operation, the program must restart so that the modifications may take effect. The following dialog box will be shown, click “Yes” to close the program, then restart the program from the Start menu.





Fig2-18 After Add, Modify, Delete operation, the program must restart

2.12 Data Report

Click the  button, the data report window will be shown:




Fig2-19 The Data Report window

To search, set the query condition, and then click the “Search” button.

Click the “Report” button to watch the report.


Click the “Excel” button to export the report in Excel format.


To delete historic data, click the “Clear” button.

Quit: quit to the main window.

2.13 Use ElectronicLoad software control your load

Start the ElectronicLoad program, from the Eload List, select the load you want to use. If the desired load does not appear on the Eload List, use Eload Setting to add the desired load.

Click the  Setting button, ensure that the Com port, baud rate and address is the same as that of the load..

Click the  Start button to start communication. Using the Control Mode switch, set the load in PC control mode; You may now control the load from the computer.

Prior to quitting the ElectronicLoad program, do remember to return the setting of your load to the Self control mode, failing which, you will be unable to control your load using it's own keyboard.

In the event of communications failure, please check the Com port, baud rate and Address settings. Also ensure that the communication cable is firmly and correctly connected.

Chapter 3 Uninstall ElectronicLoad Software


3.1 Uninstall the ElectronicLoad Software

From the Start Menu, select “Program=>Array=>Eload=>Uninstall Eload” to uninstall the software. Remember to quit the program before uninstalling.

Apéndice C

Manuales de los instrumentos

C.3 Carga electrónica Array 710A, Protocolo de comunicaciones



Control Protocol for Electronic Load Instrument

A. Default Serial Communications Port Settings

- 1) Baud Rate: 9600
- 2) Data Bits: 8
- 3) Stop Bits: 1
- 4) Handshake: None

B. Frame Format (applies to both transmitted and received data)

The frame length is 26 bytes with the following format:

AAh	Address	Command	Relative information: Bit 4 - 25	Checksum
-----	---------	---------	----------------------------------	----------

Description of frame bytes:

- 1) The first byte of the frame is always AAh
- 2) The second byte is the instrument address (00h to FEh as set using front panel menu)
- 3) The third byte is the instrument control Command (90h to A0h)
These are the possible commands:
 - 1) 90h-----Set max current, max power and Set-value.
 - 2) 91h-----Read current, Voltage, power and instrument's state
 - 3) 92h-----To control the ON/OFF state of the load
 - 4) 93h-----Programmed test sequence, define odd step1-5
 - 5) 94h-----Programmed test sequence, define odd step 6-10
 - 6) 95h-----Start programmed test sequence
 - 7) 96h-----Stop programmed test sequence
- 4) Bytes 4 through 25 are the instrument data being sent or received
 - 1) the Voltage range of 0-360V is represented by an integer in the range of 0-360000.
 - 2) the current range of 0-30A is expressed as an integer in the range of 0-30000.
 - 3) the power range of 0-200W is expressed as an integer in the range of 0-2000.
 - 4) the resistance range of 0-500Ω is expressed as an integer in the range of 0-50000.
- 5) Byte 26 is the Checksum obtained by adding the values of the previous 25 bytes.

For example, this is the command you would use to query the state of the instrument ...
AA 01 91 00 3C

C. Command Descriptions

90h, Set load operating parameters and maximum limits

Byte 1	AAh (frame start)
Byte 2	Address (00h - FEh)
Byte 3	90h (command)
Byte 4	Low byte of the maximum current
Byte 5	High byte of the maximum current
Byte 6	Low byte of the maximum power
Byte 7	High byte of the maximum power
Byte 8	New address of the Load (change address)
Byte 9	Type of set-value; 01h = current, 02h = power, 03h =resistance
Byte 10	Low byte of set-value
Byte 11	High byte of set-value
Byte 12 - 25	System Reserved
Byte 26	Checksum

The set-values for current, power and resistance are all expressed by two bytes. The Low byte is sent first. For example, the set-value 3589h is specified by the following sequence:

89h	35h
-----	-----

91h, Read current, voltage, power and resistance of the instrument

Byte 1	AAh (frame start)
Byte 2	Address (00h—FEh)
Byte 3	91h (command)
Byte 4	Low byte of the current
Byte 5	High byte of the current
Byte 6	Low byte of the low character of the voltage
Byte 7	High byte of the low character of the voltage
Byte 8	Low byte of the high character of the voltage
Byte 9	High byte of the high character of the voltage
Byte 10	Low byte of the power
Byte 11	High byte of the power
Byte 12	Low byte of the max current
Byte 13	High byte of the max current
Byte 14	Low byte of the max power
Byte 15	High byte of the max power
Byte 16	Low byte of the resistance value
Byte 17	High byte of the resistance value
Byte 18	Output state of the electronic load
Byte 19 - 25	System reserved
Byte 26	Checksum

The output state of the load is revealed by the individual bits of byte18:

From High to Low

b7	b6	b5	b4	b3	b2	b1	b0
----	----	----	----	----	----	----	----

b0: 0 = local (front panel) control ; 1 = remote (PC) control

b1: 0 = load OFF; 1 = load ON.

b2: 0 = correct polarity detected; 1 = wrong polarity detected

b3: 0 = temperature in acceptable range; 1 = excessive temperature

b4: 0 = Voltage acceptable; 1 = excessive Voltage.

b5: 0 = power acceptable; 1 = excessive power

Note: values of bytes 4 through 18 in command string will be ignored by instrument (suggest setting these to 00h); reply from instrument will have valid data in bytes 4 through 18.

92h, Activate or de-activate load and set local/remote control

Byte 1	AAh
Byte 2	Address (00h-FEh)
Byte 3	92h (command)
Byte 4	State of the electronic load
Byte 5- 25	System Reserved
Byte 26	Checksum

The desired state of the load is specified by the individual bits of byte4:

From High to Low

b7	b6	b5	b4	b3	b2	b1	b0
----	----	----	----	----	----	----	----

b0: 0 = load OFF; 1 = load ON

b1: 0 = go to local mode (front panel control); 1 = go to remote control (PC in control)

93h, Define programmed test sequence, steps 1-5

Byte 1	AAh
Byte 2	Address (00h—FEh)
Byte 3	93h (command)
Byte 4	Type of setting; 01h = current, 02h = power, 03h = resistance
Byte 5	Total number of program steps (1-10)
Byte 6	Low byte of step 1 setting
Byte 7	High byte of step 1 setting
Byte 8	Low byte of step 1 duration (seconds)
Byte 9	High byte of step 1 duration
Byte 10	Low byte of step 2 setting
Byte 11	High byte of step 2 setting
Byte 12	Low byte of step 2 duration
Byte 13	High byte of step 2 duration
Byte 14	Low byte of step 3 setting
Byte 15	High byte of step 3 setting
Byte 16	Low byte of step 3 duration
Byte 17	High byte of step 3 duration
Byte 18	Low byte of step 4 setting
Byte 19	High byte of step 4 setting
Byte 20	Low byte of step 4 duration
Byte 21	High byte of step 4 duration
Byte 22	Low byte of step 5 setting
Byte 23	High byte of step 5 setting
Byte 24	Low byte of step 5 duration
Byte 25	High byte of step 5 duration
Byte 26	Checksum

94h, Define programmed test sequence, steps 6-10

Byte 1	AAh
Byte 2	Address (00h—FEh)
Byte 3	94h (command)
Byte 4	Low byte of step 6 setting
Byte 5	High byte of step 6 setting
Byte 6	Low byte of step 6 duration
Byte 7	High byte of step 6 duration
Byte 8	Low byte of step 7 setting
Byte 9	High byte of step 7 setting
Byte 10	Low byte of step 7 duration
Byte 11	High byte of step 7 duration
Byte 12	Low byte of step 8 setting
Byte 13	High byte of step 8 setting
Byte 14	Low byte of step 8 duration
Byte 15	High byte of step 8 duration
Byte 16	Low byte of step 9 setting
Byte 17	High byte of step 9 setting
Byte 18	Low byte of step 9 duration
Byte 19	High byte of step 9 duration
Byte 20	Low byte of step 10 setting
Byte 21	High byte of step 10 setting
Byte 22	Low byte of step 10 duration
Byte 23	High byte of step 10 duration
Byte 24	Program mode (00h = run once; 01h = repeat)
Byte 25	System Reserved
Byte 26	Checksum

95h, Start programmed test sequence

Byte 1	AAh
Byte 2	Address (00h-FEh)
Byte 3	95h (command)
Byte 4 - 25	System Reserved
Byte 26	Checksum

96h, Stop programmed test sequence

Byte 1	AAH
Byte 2	Address (00h-FEh)
Byte 3	96h (command)
Byte 4 - 25	System Reserved
Byte 26	Checksum